


# USB Turntable & Cassette Converter (USBT007)


## Quick Start Guide (For full instructions visit [http://wiki.audacityteam.org/wiki/USB\\_turntables](http://wiki.audacityteam.org/wiki/USB_turntables))

### 1. How do I setup Audacity to record my LPs and cassettes?



**Step 1:** Open Audacity.

**Step 2:** Go to **Edit** → and click **Preferences**.



**Step 3:** While in the **Audio I/O** Tab select your default sound device or sound card by name as the playback device.

**Step 4:** Depending on what is available, select **USB Audio CODEC**, **USB Turntable**, **USB PnP Audio Device** or **Microphone Array** as the recording device.

**Please note:** Your option may be labelled differently as what you see depends on your PC's configuration – in this case simply select the closest match to the above.

**Step 5:** Set Recording Channels to 2 (Stereo).

**Step 6:** Optionally, enable **Software Playthrough** if you want to hear the turntable through your computer speakers while recording.

**Step 7:** Click Ok. You can now record your LPs and cassettes during play back.

# USB Turntable & Cassette Converter (USBT007)

## Quick Start Guide (For full instructions visit [http://wiki.audacityteam.org/wiki/USB\\_turntables](http://wiki.audacityteam.org/wiki/USB_turntables))

---

### 2. How do I install the LAME MP3 Encoder to export MP3s?

- Step 1:** Insert the Installation Disc into your CD-ROM drive and locate the *lame\_enc.dll* file.
- Step 2:** Copy this file and save it into your Audacity installation folder. This is normally at C:\Program Files\Audacity.
- Step 3:** Launch Audacity and click **Edit** → **Preferences**.
- Step 4:** Select the **File Formats** Tab and look for the **MP3 Export** section.
- Step 5:** Click on the "Find Library" or "Locate..." button.
- Step 6:** When prompted to locate the LAME encoder click "Yes" then go to the folder where you put *lame\_enc.dll* earlier and select it.
- Step 7:** Click Open, then OK.

**For additional assistance and tips on MP3 Encoding be sure to visit this link:**  
[http://wiki.audacityteam.org/index.php?title=Lame\\_Installation](http://wiki.audacityteam.org/index.php?title=Lame_Installation)

### 3. How do I adjust the recording volume?

Sometimes you may find that the input level from the turntable is either too high or too low during recording. To adjust the input level, try turning the volume up or down (as appropriate) in the system mixer.

For example, in Windows 7:

- Step 1:** Right-click over the speaker icon in the System Tray → and then click **Recording Devices**.
- Alternatively, click Windows Start → Control Panel → Hardware and Sound → Sound, then click the **Recording** tab.
- Step 2:** Right-click over "USB Audio CODEC, USB Turntable, USB PnP Audio Device or Microphone Array" (or whatever is similarly labelled) and hit **Properties**.
- Step 3:** Click the **Levels** Tab and turn up or turn down the input level for the device.
- Then click Ok to close the window.

**For additional assistance and tips on adjusting audio levels be sure to visit this link:**  
[http://wiki.audacityteam.org/wiki/Mixer\\_Toolbar\\_Issues#vistacp](http://wiki.audacityteam.org/wiki/Mixer_Toolbar_Issues#vistacp)